

Complete the following instructions, once you finished connecting the device,

1. Pick the handset of the analog phone which is connected to the CISCO ATA, and press the lit red button and dial 322873738#.
2. The voice prompt will ask you to dial '\*' to save changes you have just made. Press '\*' and hang up the phone set. This will reset to the factory defaults of the device.

### Checking the IP address through the IVR

1. Restart the device. When the device is in the ready mode, pick the phone's handset and press the lit red button.
2. You will hear the IVR Prompt. Then press '80#'. The IVR will repeat the IP address which is allocated for this device.

Note: By default DHCP is enabled.

### Getting to web interface:

1. Type the IP address of the device on the browser (eg: Internet Explorer) as stated below.  
(<http://device IP/dev>)
2. You see the entire configuration of your CISCO ATA 186/188

### The Cisco ATA can run on two protocols:

1. SIP
2. H323

Below is the configuration page which will guide you to configure the CISCO ATA which uses the SIP Protocol (**PLEASE NOTE THE RED OUTLINED SETTINGS**):

## Cisco ATA 186 (SIP) Configuration

UIPassword:	*	UseTftp:	1
TftpURL:	0	CfgInterval:	3600
EncryptKey:	*	EncryptKeyEx:	000000000000000000000000
Dhcp:	1	StaticIP:	0.0.0.0
StaticRoute:	0.0.0.0	StaticNetMask:	255.255.255.0
UID0:	Username 1	PWD0:	Password 1
UID1:	Username 2	PWD1:	Password 2
GkOrProxy:	sip.yapcalls.com	UseLoginID:	0
LoginID0:	0	LoginID1:	0
AltGk:	0	AltGkTimeOut:	0
SIPRegInterval:	240	MaxRedirect:	5
SIPRegOn:	1	NATIP:	0.0.0.0
SIPPort:	5060	MediaPort:	16384
OutBoundProxy:	0.0.0.0	NatServer:	0
NatTimer:	0x00000000	MsgRetryLimits:	0x00000000
SessionTimer:	0x00000000	SessionInterval:	1800
MinSessionInterval:	1800	DisplayName0:	0
DisplayName1:	0	LBRCCodec:	0
AudioMode:	0x00150015	RxCodec:	1
TxCodec:	1	NumTxFrames:	2
CallFeatures:	0x00000000	PaidFeatures:	0x00000000
CallerIdMethod:	0x00019e60	FeatureTimer:	0x00000000

FeatureTimer2:	0x0000001e	Polarity:	0x00000000
ConnectMode:	0x000060400	TimeZone:	17
NTPIP:	0.0.0.0	AltNTPIP:	0.0.0.0
DNS1IP:	0.0.0.0	DNS2IP:	0.0.0.0
TOS:	0x000068b8	SigTimer:	0x01418564
OpFlags:	0x00000002	VLANSetting:	0x0000002b
FXSInputLevel:	-1	FXSOutputLevel:	-4
NPrintf:	0.0.0.0	TraceFlags:	0x00000000
SyslogIP:	0.0.0.0.514	SyslogCtrl:	0x00000000
RingOnOffTime:	2,4,25	IPDialPlan:	1
DialPlan:	*St4- #St4- 911 1>#t8.r9t2	DialPlanEx:	0
DialTone:	2,31538,30831,1380,174	BusyTone:	2,30467,28959,1191,151:
ReorderTone:	2,30467,28959,1191,151:	RingBackTone:	2,30831,30467,1943,211:
CallWaitTone:	1,30831,0,5493,0,0,2400,	AlertTone:	1,30467,0,5970,0,0,480,4
SITone:	0,0,0,0,0,0,0,0,0,0,0,0,	CallCmd:	At;AH;BS;NA;CS;NA;Df;
CFGID:	0x00000000		